CIRRUS

Rechargeable E Cigarette

User Manual

WHITE CLOUD
ELECTRONIC CIGARETTES

www.whitecloudelectroniccigarettes.com

Quick Start Guide

All Cirrus rechargeable e cigarette batteries are charged and ready to use right out of the box! All you need to do to get started is attach a SmoothDraw or ClearDraw Cartridge to the battery.

To connect the electronic cigarette cartridge and battery, first, remove the clear rubber caps from each end of a SmoothDraw Cartridge.

Attach the SmoothDraw or ClearDraw Cartridge to the E-Cigarette Battery. We recommend you hold ClearDraw Cartridges close to the threaded coupler when attaching.

Smoothdraw and Cleardraw Cartridges will work with all Cirrus E Cigarette battery models.

When the cartridge is attached to the battery, begin smoking by taking long gentle puffs. The LED ash tip will glow with each puff.

(NOTE: If you have a Phantom battery or a blackout ash tip on your Cirrus battery, the LED will not illuminate.)

Cirrus Charging

When the LED ash tip flashes repeatedly, it is time to recharge the battery. Remove the cartridge and set it aside.

Twist the battery into the Chargebolt or Squid USB smart e cigarette charger.

Insert the USB smart charger into an open USB port on your computer to begin charging. You can also attach the smart charger to our AC or DC adapter to charge from a wall outlet or or your car's DC outlet (cigarette lighter).

The WC logo on the USB charger will glow red when the Cirrus battery is charging.

The logo will glow blue when it is complete (approximately 90-120 minutes).

(NOTE: The LED ash tip may illuminate during charging, this is normal and does not indicate a malfunction.)

Warnings Against Improper Use Of Cirrus E Cig Cartridges

- You should not use this product if you are not of the required age, as designated by law, are a non-smoker, if you have an allergy or sensitivity to nicotine or any combination of inhalants, if you are pregnant or breastfeeding, have heart disease, diabetes, high blood pressure, asthma or any other serious medical condition.
- Certain studies suggest that nicotine may cause addiction in certain users. Should such dependency result, stopping use of SmoothDraw cartridge may cause discomfort and other potentially injurious side effects. There have also been certain studies that indicate that nicotine may be dangerous if used in excess amounts.
- Do not add any liquid to a cartridge or any component. Doing so will void any and all warranties.
- Take care not to drop the unit, as this may cause damage to the battery.
- The e cig charger should not be used outdoors, in a damp environment, or near water.
- Avoid storing the White Cloud Cirrus and SmoothDraw cartridges in extreme temperatures (below 32°F and above 125°F).
- Do not use attachments that are not recommended by the manufacturer.
- The battery should be charged only from the supplied USB charger connected to a USB port or an approved AC or DC adapter.
- Do not place the unit or its charger near gas or electric heaters, fireplaces, candles or other similar sources of heat.
- Do not pierce the battery.
- In case of peculiar smell, heat generation, discoloration, distortion or any abnormality of the battery during the charging process, disconnect the power supply, remove the battery from the charger and do not use the battery